



SEE REVERSE SIDE FOR INSTRUCTIONS



Start by removing the backboard and mat from your frame. Gently push the tassel shadowbox through the backboard.

1



Insert your tassel through the slot in the top of the shadowbox and pull down 1/2 inch.

2



Place tape (not provided) across the loop. Firmly press the tape to the back of the shadowbox.

3



The excess loop can be draped over the backboard when closing up the back of the frame. **Enjoy your framed document!**

4